

Seismic Clamping Pipe Attachment



Function: Designed for bracing pipe against sway and seismic disturbance. The pipe attachment component of a sway brace system used in conjunction with a UTT Manufacturing structural attachment fitting, and joined together with a bracing pipe element forms a complete sway brace assembly. Sway brace assemblies are intended to be installed in accordance with NFPA 13 and the manufacturer's installation instructions.



Type: Sprinkler Pipe Sch 10, Sch 40, GB/T 3091, JIS G3454

Size: Pipe size 2" thru 8"

Material: Carbon Steel


Finish: Electro-galvanized

Approvals:



UL Maximum Design Load					
Part Number	Pipe Size	lbs.	KN	Wt. Each	
				1" Brace Pipe	
				lb.	kg
2550643A	2	680	(3.02)	2.33	(1.06)
2550644A	2½	680	(3.02)	2.42	(1.1)
2550645A	3	680	(3.02)	2.55	(1.16)
2550647A	4	680	(3.02)	2.73	(1.24)
N/A	5	1090	(4.84)	3.92	(1.78)
2550649A	6	1370	(6.09)	4.29	(1.95)
N/A	8	1370	(6.09)	4.93	(2.24)

FM Maximum Design Load							
Part Number	Pipe Size	Horizontal load ratings installation angle 30°-44°		Horizontal load ratings installation angle 45°-59°		Wt. Each	
		lbs.	kN	lbs.	kN	1" (25mm) Brace Pipe	
						lb.	kg
2550643A	2	1070	(4.75)	1440	(6.40)	0.92	(0.42)
2550644A	2½	840	(3.73)	1120	(4.98)	1.01	(0.46)
2550645A	3	1030	(4.58)	1560	(6.93)	1.08	(0.49)
2550647A	4	650	(2.89)	890	(3.95)	1.21	(0.55)
2550649A	6	830	(3.69)	1250	(5.56)	1.52	(0.69)
N/A	8	880	(3.91)	1150	(5.11)	1.81	(0.82)



Install:

Install the pipe clamp to the pipe, then install the bolts and nuts as the shown picture. The accessories of UTT20 use the sch40 1-inch pipe, The nuts torque of UTT 20 need to reach 100~115N • M to make all green marking lines visible in the bolts. After the installation of bolts & nuts and other accessories, the pipe must be clamped to the bottom of the accessories.

System No.		Location	
Submitted By		Date	

Spec Section		Paragraph	
Approved		Date	